


# MAP 330 Quick Reference



## Battery Installation

Do NOT remove batteries from the MAP 330 while it is turned on.

## Specifications

12 parallel-channel technology tracks up to 12 satellites

Quadrifilar antenna

Acquisition times of 15 seconds for warm start, 1 minute for cold start

Update rate: 1 second continuous

Accuracy: 49 feet (15 meters) RMS

Maximum computed speed of 951 mph; maximum computed elevation of 17,500 meters

Weatherproof with wraparound rubber armor

Powered by 2 AA batteries or 9-35 VDC external power source

Battery life with display backlight turned off of 10 hours

PN 630779

## Turning MAP 330 On




## Setting Display Backlight




## Adjusting Contrast



## Selecting Nav Screen




## Saving a Waypoint



## Creating a GOTO Route




Highlight



960 Overland Court  
San Dimas, CA 91773  
(909) 394-5000


## Navigational Screens




### Map Screen

**MENU** Access map setup features & MAP 330 functions


**IN** **OUT** Zoom

 Pan to map objects



### Compass Screen

**MENU** Access customize features & MAP 330 functions



### Large Data Screen


**MENU** Access customize features & MAP 330 functions



### Position Screens

**MENU** Access customize features & MAP 330 functions

 Access 2nd Position screen



### Sat Status Screen

**MENU** Access MAP 330 functions

## Setup

### Accessing Setup

**MENU** Highlight **ENTER** Setup

### Setup Options

**Initialize** Use after travelling over 500 miles with MAP 330 turned off or after memory loss.

**Nav Screens** Turns navigation screens on/off

**Coord System** Default: LAT/LON, DEG.MIN.MMM

**Map Datum** Default: WGS84

**Elev Mode** Default: 3D

**Time Format** Default: Local AM/PM

**Nav Units** Default: Miles/MPH

**North Ref.** Default: Magnetic

**Light Timer** Default: 4 Minutes

**Beeper** Default: Keys & Alarms

**Clear Memory** Clear track history, wpts/routes, back wpts, routes, reset defaults or all.

**NMEA** Default: Off

**Baud Rate** Default: 4800 Baud

**Simulate** Activate simulator in User or Auto mode or turn off simulator.